

Pool Owner

Preventive Maintenance

Cleaning Your Pool Heater:

Your Trevor-Martin Corporation Pool Heater does not require much routine maintenance. 3-4 times a year you should clean all three (3) sides of the outside coil. First you should shut off all power to the Pool Heater at the breaker box. Using a garden hose, spray the outside coils of the Pool Heater. In each of the corners of the resin base are drain holes. Using a garden hose, spray down through the fan opening, to clean out the drain holes. The condensation formed when a Trevor-Martin Pool Heater runs can produce 8-10 gallons of water a day. This must be able to drain away from the Pool Heater.

NOTE: Homes within two (2) miles of the ocean or any brackish canals must clean coil and resin base every month to prevent salt air corrosion damage.

End of Season Maintenance:

Pool Heaters should not be shut down for an entire season. You must re-start your Pool Heater every month to avoid premature fan failure.

If you use a by-pass, do not leave the same water in the heat exchanger for more than seven (7) days. Allow new water into the heat exchanger to avoid possible failure due to chemical damage, which is not covered under your warranty.